





# Setting Up The Hardware

## Connecting The Printer

### Connecting the Cash Drawer to the Printer




This is the Plug for the Printer's Power Cord



This is the Port for the Printer's Power Cord  
The Printer's Power Cord

### Connecting the Cash Drawer to the Printer

One End of the Cash Drawer Cord Plugs into the Bottom of the Cash Drawer and the Other End Plugs into the Printer



Cash Drawer's Plug that Needs To be Plugged into The Printer




Where You Connect the Cash Drawer's Cord into the Printer


Cash Drawer's Cord

### Connecting the Printer to the Tablet using Bluetooth USB Connection is Only Available on our Larger 14" Tablet


**Step 1**  
Go to "Settings" on the tablet and turn on Bluetooth




**Step 2**  
Tap on "Search for Devices" and select Bluetooth Printer




**Step 3**  
Enter 1234 as the PIN and tap on the "OK" button




**Step 4**  
Within the POS app tap on this circle and then tap on "Admin" button.




**Step 5**  
Tap on "Printer Settings"



**Step 6**  
Long tap on the Bluetooth Printing row and then select Blue Tooth Printer



**Step 7**  
Check Off Bluetooth Printing and Save



**Step 8**  
Enter Receipt Header lines here then tap Save and then Exit Admin

